

Retail Application Quick Reference Guide



Hypercom® T4000 Series



Quick Reference Guide

Retail Application

Credit Card Sale

- > Swipe the card
- > Follow the prompts
- OR
- > Select [ENTER]
- > Select [TRANSACTION]
- > Select [SALE]
- > Select [CREDIT]
- > Swipe the card
- > If prompted for purchasing card press [ENTER] for yes or [CLEAR] for no
 - If prompted enter the PO/ID # and press [ENTER]
- > If prompted [ENTER] the last 4 digits of the account # and press [ENTER]
- > Enter the \$ amount and press [ENTER]
- > If prompted enter the tax amount and press [ENTER]
- > The terminal will display the total. If correct press [ENTER] to continue or [CLEAR] to return to the main screen
- > Print second receipt – [ENTER] for Yes or [CLEAR] for No

Manual Sale

- > Select [ENTER]
- > Select [TRANSACTION]
- > Select [SALE]
- > Select [CREDIT]
- > If prompted for purchasing card press [ENTER] for Yes or [CLEAR] for No
 - If prompted enter the PO/ID # and press [ENTER]
- > If prompted press [ENTER] for card present or [CLEAR] if the card is not present
 - If the card is not present select the verification code listed
- > Enter the \$ amount and press [ENTER]
- > If prompted enter the tax amount and press [ENTER]
- > The terminal will display the total. If it is correct press [ENTER] to continue or [CLEAR] to return to the main screen.
- > If prompted enter the address information
- > If prompted enter the zip code
- > Print second receipt – [ENTER] for Yes or [CLEAR] for No

Authorization Only

- > Press [ENTER]
- > Select [TRANSACTION]
- > Use the arrow key to scroll to [AUTHORIZATION ONLY] and select it
- > Swipe or manually enter card # and press [ENTER]
- > If prompted input the expiration date and press [ENTER]
- > If prompted enter the last 4 digits of the card # and press [ENTER]
- > If prompted press [ENTER] for card present or [CLEAR] if the card is not present
 - If the card is not present select the verification code listed
- > Enter the \$ amount and press [ENTER]
- > Print second receipt – [ENTER] for Yes or [CLEAR] for No

Forced Sale

- > Press [ENTER]
- > Select [TRANSACTION]
- > Select [OFFLINE]
- > Swipe or manually enter the card # and press [ENTER]
- > If prompted for purchasing card, press [ENTER] for Yes or [CLEAR] for No
- > If prompted input the expiration date and press [ENTER]
- > If prompted enter the last 4 digits of the account # and press [ENTER]
- > If prompted enter the PO # and press [ENTER]
- > Enter the \$ amount and press [ENTER]

- > If prompted enter the tax amount and press [ENTER]
- > The terminal will display the total. If it is correct press [ENTER] to continue or [CLEAR] to return
- > Input the approval code and press [ENTER]
- > Print second receipt – [ENTER] for Yes or [CLEAR] for No

Balance Inquiry

- > Press [ENTER]
- > Select [TRANSACTION]
- > Use the arrow key to scroll to [BALANCE] and select it
- > Select [PREPAID]
- > Swipe or manually enter the card # and press [ENTER]
- > A receipt will print with the available



Hypercom® T4000 Series

Debit Sale

- > Select [ENTER]
- > Select [TRANSACTION]
- > Select [SALE]
- > Select [DEBIT]
- > Swipe the card
- > Enter the \$ amount and press [ENTER]
- > If prompted enter the cash back amount and press [ENTER]
- > The terminal will display the total. If it correct press [ENTER] to continue or [CLEAR] to return to the main screen
- > Have the customer input their PIN # and press [ENTER]
- > Print second receipt – [ENTER] for Yes or [CLEAR] for No

Void

- > Press [ENTER]
- > Select [TRANSACTION]
- > Use the arrow key to scroll to [VOID] and select it
- > Input the invoice # and press [ENTER]
- > The terminal will display the total. If it is correct press [ENTER] to continue or [CLEAR] to return
- > Print second receipt – [ENTER] for Yes or [CLEAR] for No

Credit Return

- > Press [ENTER]
- > Select [TRANSACTION]
- > Select [REFUND]
- > Select [CREDIT]

- > Swipe or manually enter the card # and press [ENTER]
- > If prompted input the expiration date and press [ENTER]
- > If prompted enter the last 4 digits of the account # and press [ENTER]
- > Enter the \$ amount and press [ENTER]
- > Print second receipt – [ENTER] for Yes or [CLEAR] for No

Debit Refund

- > Press [ENTER]
- > Select [TRANSACTION]
- > Select [REFUND]
- > Select [DEBIT]
- > Swipe the card
- > If prompted enter the last 4 digits of the account # and press [ENTER]
- > Enter the \$ amount and press [ENTER]
- > Have the customer enter their PIN # and press [ENTER]
- > Print second receipt – [ENTER] for Yes or [CLEAR] for No

Find

- > Press [ENTER]
- > Select [BATCH]
- > Use the arrow keys to scroll to [FIND] and select it
- > Input the invoice # and press [ENTER]

Reprint

- > Press [ENTER]
- > Use the arrow key to scroll to re-print and select it
- > Select [LAST] to print the last transaction or [INVOICE] to enter a specific invoice #
- > Select customer or merchant copy

The receipt will reprint

Settlement

- > Press [ENTER]
- > Select [BATCH]
- > Select [SETTLEMENT]
- > Enter the manager password and press [ENTER]
- > The terminal will display the sale total. If it correct press [ENTER] to continue or [CLEAR] to return
- > The terminal will display the refund total. If it correct press [ENTER] to continue or [CLEAR] to return
- > The terminal will settle the batch and print a settlement report

NOTE: If totals are incorrect run an audit to determine what transactions are missing and re-run them.

Batch Review

- > Press [ENTER]
- > Select [BATCH]
- > Select [REVIEW]
- > Use the [CLEAR] key to view the previous transaction or [ENTER] to view the next transaction

Totals

- > Press [ENTER]
- > Select [BATCH]
- > Select [TOTALS]
- > The batch is scanned and the total \$ amount for the batch displays
- > Press [ENTER] to review net sales by card type and continue to as needed
- > Press [CLEAR] to review previous totals. When the last card is shown the terminal displays 'NO MORE TOTALS'

Detail Report

- > Press [ENTER]
- > Press [REPORTS]
- > Select [AUDIT]
- > Select [NOVA]

A detailed breakdown of the transaction will print

Summary Report

- > Press [ENTER]
- > Select [REPORTS]
- > Select [SUMMARY]

The report will print

History Report

- > Press [ENTER]
- > Press [REPORTS]
- > Use the arrow key to scroll to [HISTORY] and select it
- > Select the length of days history you want to print

The report will print



MerchantConnect

The Online Window To Your Payment Processing Account

MerchantConnect is your one-stop destination for online customer service. It contains everything you need to manage your electronic payment activity:

My Account

Manage your account online. View statements, view or update your profile, request new products and track equipment shipments.

My Reports

Provides you with timely and secure accounting information such as deposit summaries, transaction activity, chargeback and retrieval status and more.

Support

Find resource information about transaction processing, industry mandates, product support and practical tips to help improve your bottom line.

Getting Started Is:

Fast, Easy, Secure And Free!

Go to www.MerchantConnect.com